

ARCS PROCEDURE:	ADaM RESTART PROCEDURE	PRO(ADAM)-004.002
Author: A. Koontz		July 16, 1998 Page 1 of 1

ADaM Restart Procedure

I. Purpose:

This document describes the procedure to restart ADaM at the Tropical Western Pacific site.

II. Cautions and Hazards:

- **Do Not** use this procedure unless specifically instructed to restart ADaM by TWPPO.

III. Requirements:

None.

IV. Procedure:

A. Steps:

1. Go to the ADaM computer terminal located in the D-Van.
2. Turn on the Phase-X monitor.
3. Turn on the Phase-X terminal.
4. Open the cabinet.
5. Turn ON the green power switch in the right hand cabinet.
6. You then see the lights go on and hear the fans go on.
7. Text messages begin appearing on the terminal screen.
8. After about 20 minutes the ADaM application banners appear across the top and bottom of the Phase-X monitor screen.
9. ADaM is now restarted.

V. References:

None.

VI. Attachments:

None.